

# Evaluating Antineutrino-Based Safeguards using the RETINA System

Presented by **Matthew Dunbrack**

**2023 LANNS Symposium-2**



**LANNS**


LABORATORY FOR ADVANCED NUCLEAR  
NONPROLIFERATION AND SAFETY

November 3, 2023




# Introduction

The International Atomic Energy Agency (IAEA)



■ States with Nuclear Power Plants




New Sites

More Reactors

Novel Designs

# Motivation




How do we know reactors are operating as declared?

# Background


## The Reactor Evaluation Through Inspection of Near-field Antineutrinos (RETINA) System

**Design** relevant environments




Antineutrino  
Detector



**Simulate** potential reactor conditions



**Deduce** the current reactor state



# Evaluating Antineutrino-Based Safeguards



	Log In Declaration	Log In Alternative
<b>Reactor Age</b> [EFPYs]	7.2	0
<b>Reactor Power</b> [MWth]	250	250
<b>Standoff Distance</b> [m]	17	17
<b>Background Knowledge</b> [events]	Simulated bkgd collection	Simulated bkgd collection
<b>Collection Period</b> [days]	30	
<b>Probability of Detection</b>	62.4%	



# Scenario Sensitivity Challenges

Assessing Sensitivity with  
ML Processing

Assessing Sensitivity for  
Specific Scenarios

(Old Results)	Individualized Models (Detection Probability)	Unseen Models (Detection Probability)
Diverted 1 Assembly	2.28%	1.40%
Diverted 2 Assemblies	0.27%	< 0.01%
Diverted 3 Assemblies	0.15%	< 0.01%


Does not work well for  
"unseen" scenarios

Limited computational resources means  
there will always be unseen scenarios



# Future Work

**Temporal Difference Learning**  
Test and Learn from Unseen Scenarios



The system will converge to a **global diversion detection sensitivity** using the most **robust model**



**LANNS**

LABORATORY FOR ADVANCED NUCLEAR  
NONPROLIFERATION AND SAFETY

# Acknowledgement



The Consortium for Monitoring, Technology, and Verification would like to thank the DOE-NNSA for the continued support of these research activities.



This work was funded by the Consortium for Monitoring, Technology, and Verification under Department of Energy National Nuclear Security Administration award number DE-NA0003920.





# Thank you



## LANNS

LABORATORY FOR ADVANCED NUCLEAR  
NONPROLIFERATION AND SAFETY

# References

1. Office of Nuclear Energy. “Advanced Reactor Technologies.” *Energy.gov*
2. Waldrop, M. M. *Nuclear goes retro - with a much greener outlook*. Knowable Magazine | Annual Reviews



**LANNS**

LABORATORY FOR ADVANCED NUCLEAR  
NONPROLIFERATION AND SAFETY

# Extra Slides

# Detection Probability Objective Functions

We've created a methodology for guiding detection objectives using **State-Specific Factors (SSFs)**, or safeguards relevant factors used by the IAEA to develop State-level safeguards approaches

SSF-1  
Safeguards  
Agreement

SSF-2  
Fuel Cycle  
Capabilities

SSF-3  
SSAC  
Capabilities

SSF-4  
Implementing  
Safeguards

SSF-5  
State  
Cooperation

SSF-6  
Experience  
with State

$$\text{Detection Probability}_{\text{Scenario}} = \alpha * DP_{\text{SSF-1}} + \beta * DP_{\text{SSF-2}} + \gamma * DP_{\text{SSF-3}} + \delta * DP_{\text{SSF-4}} + \epsilon * DP_{\text{SSF-5}} + \zeta * DP_{\text{SSF-6}}$$

# Technical Approach

## The Reactor Evaluation Through Inspection of Near-field Antineutrinos (RETINA) System

### Spectra Simulation

Customizable Objects

- Reactors
- Detectors
- Scenarios

Modular Configuration

- Plug-in inputs from outputs
- Multiple reactors and detectors allowed

### Diversion Simulation

Customizable Reactor Inventories

- High-fidelity diversion modeling with customizable diversion assemblies, elements, quantities, and replacement fuel

### System Sensitivity

Spectra Processing

- Null and Alternative Spectra from User-Input Objects


Profile Construction for Parameter Convergence

- Detection Probability
- Verification Collection Period
- Boundaries

End users can **evaluate** potential use cases and **develop** strategic system improvements



# Antineutrino Detection



Inverse-Beta Decay:  $\bar{\nu}_e + p = e^+ + n$

# Profile Construction

## Generate Sample Detection Spectra

$$y_{i,0} \sim N(\text{Counts}_{Bkgd,i}, \sigma_{\text{Counts}_{Bkgd,i}})$$

$$x_{i,0} \sim \text{Pois}(y_{i,0} \mid y_{i,0} \in W)$$

$$y_{i,1} \sim N(\text{Counts}_{Tot,i}, \sigma_{\text{Counts}_{Tot,i}})$$

$$x_{i,1} \sim \text{Pois}(y_{i,1} \mid y_{i,1} \in W)$$

## Determine Likelihood Values and Form Ratio Profiles

$$\lambda_0 = \ln\left(\frac{\prod_{i=0}^{15} L(x_{i,0} \in X_{i,0})}{\prod_{i=0}^{15} L(x_{i,0} \in X_{i,1})}\right) \quad \lambda_1 = \ln\left(\frac{\prod_{i=0}^{15} L(x_{i,1} \in X_{i,0})}{\prod_{i=0}^{15} L(x_{i,1} \in X_{i,1})}\right)$$

## Repeat Until Reaching our Desired Statistics

